

The program BC451Setup###.exe is executable starting from WIN95. It needs not to be installed and can from any place be started (USB stick, desktop, etc.).

The driver for the USB Dongle must be only installed. Following approach is to be considered!

Driver installation if you still no USB Dongle have:

1. Install first the file CDM 2.04.06 by Doppelclick (USB Dongle driver)
2. Copy the file BC451Setup### as well as the file ftd2xx.dll on your desktop
3. Start the program BC451Setup###

Special case when starting without installed Dongle:

The files file BC451Setup###.exe & ftd2xx.dll must be at the same place!

Installation software if you a USB Dongle have:

1. Install first the file CDM 2.04.06 by Doppelclick (USB Dongle driver)
2. Subsequently, you connect the USB cable (Dongle) with its computer (the driver now automatically furnished).
3. Start the program BC451Setup###
Now you can configure the BC according to your desires.